

## Towerfix® Turntable

### 1. General

The **Towerfix® Turntable** set contains:

- Turntable
- Motor (230V) incl.. Power supply
- 4 Screw and 4 wing nuts



### 2. Handling

- 1) The Motor has a standing and a rotating part. The standing part is knowing by the power supply Cable (white). Take the Motor with the rotating part upward.
- 2) Put the Plate with the blind holes upward to the motor.
- 3) Pull the black cable through the big hole.
- 4) Mount the Plate with the four screws and wing nuts to the motor.



#### For Flashed Tower:

Mount the Flash cable to the black power supply cable (230V)

